# How do I measure my leaf springs?

**Flat Lengths** are measured from the center of each eye to the center pin of the leaf spring.

**Camber** is measured from the first leaf to the top of the eye. To measure camber, place the spring upside down on a flat surface, and then measure the distance from the first leaf to the surface.

