FORD F150


INSTALL RESERVOIR TO REAR OF VEHICLE
ON BOTH LEFT AND RIGHT SIDE.
KEEP AS HIGH AS POSSIBLE WITH THE
HOSE TOWARDS THE OUTSIDE OF SHOCK
ENSURE REBOUND ADJUSTERS ARE
ACCESSIBLE ON BOTH SIDES