SC59-022
Fitting Instructions

Front of Vehicle

Drivers Side



Passenger Side



When installing the strut top caps, ensure the drivers side arrow is pointing toward the front of the vehicle and the passenger side toward the rear of the vehicle. The shock **Banjo** should be aligned perpendicular to the arrow, pointing at the frame.