



Fitment	Part Number
WK2 Front Strut	GS/IMS/MRA Ending in 732/742

Install Instructions

NOTE – Installation is always recommended by a competent technician.



BOTH SIDES: To install please remove the top ball joint, the sway bar link, tie rod end and loosen ABS LINES.

LEFT SIDE Remove the CV from the WHEEL/HUB END. As Dobinsons front struts allow a lot more travel, for ease of removal, remove the front diff bolt as per arrow, to allow the strut to be installed and removed easily. This will drop the CV enough to get the strut clevis past the wheel end of the CV.

Set the Centre of hole of clevis to the base of the coil (where coil sits on the spring seat) to 540mm. This can be adjusted up and down. Every 1mm of adjustment gives 2mm of height on the car. Check for any clearance issues if adjusting to any height which is not standard.