

TOYOTA LANDCRUISER 300 SERIES

RESERVOIR BOLTED TO MOUNT AS SHOWN USING HANDLE NUTS THROUGH EXISTING CHASSIS HOLES. GLUE/STICK LARGE DIAMETER 8MM WASHER SUPPLIED TO HANDLE NUT ON THE LOWER LARGER HOLE TO PREVENT HANDLE NUT BENDING INTO HOLE. RE-INSTALL PLASTIC SHROUD WITH PLASTIC CLIP IN REAR HOLE. DRILL FRONT HOLE TO FIT NEATLY OVER BOLT HEAD.

ROUTE HOSE FORWARD AND TO THE INSIDE ABOVE SWAYBAR AND BELOW STEERING ARM. AT FULL DROOP HOSE TO BE RELATIVELY TIGHT WITH AROUND 5- 10MM GAP TO LOWER PLASTIC SHROUD. SECURE WITH P CLAMP TO EXISTING BOLT HOLE

