



Fitment	Part Number
Toyota Landcruiser 100	MRA59-A782 MRA59-A786

## Reservoir Install Instructions

**NOTE – Installation is always recommended by a competent technician. Failure to properly install may result in reservoir fouling on components and voiding warranty.**

### WARNING:

- Do not let gas out of shocks unless you have the ability to re-charge the shocks.
- Care must be taken to ensure the external oil reservoir does not foul on any components over the full travel.
- Operation outside of the working range may cause damage to the arm and could result in component failure, Warranty may also be voided.



### Washer Sequence

Dobinsons Springs and Suspension  
Hollingsworth Street  
Australia/USA/UAE

58 Hollingsworth Street  
NORTH ROCHAMPTON QLD AUSTRALIA  
[admin@dobinsonsprings.com](mailto:admin@dobinsonsprings.com)

1. Mount shock absorber as per original configuration with the body at the top and the rod at the bottom.
2. Make sure the hose is facing slightly forward as per below picture.



3. Mount the bracket into location shown with hose and res as per picture.



## Other fitting Notes

*Make sure top nut is tight.*

*Please check the reservoir and the hose clear all arms etc on full travel up and down.*

*Place all stickers on the shock to outside of car for maximum visual effect.*

*Put on zipties to hold the dust cover in position.*